



Reference Formula

Sample preparation date: 2023/04/19

3D Gentle Cleaning Mousse

M230502-1

FORMULA

Phase	Ingredient (Trade Name)	Ingredient (INCI Name)	% By Weight	Function
W1	D.I Water	D.I Water	Up to 100%	Solvent
	FOAMYSENSE™ 205 Polymer¹	PEG-14M	0.07%	Skin feel modifier
	TILAMAR® PDO with NØØVISTA™²	Propanediol	3.00%	Moisturizer
	Amphosol® CDB HP¹³	Cetyl Betaine	8.00%	Surfactant
W2	ERCAMILD LS-30¹⁴	Sodium Lauroyl Sarcosinate	7.00%	Surfactant
	SHAROSURF S4²⁵	Sodium PEG-7 Olive Oil Carboxylate	15.00%	Surfactant
	SHAROSURF S3²⁵	Olive Oil PEG-7 Esters	2.00%	Emollient
W3	Aloe Vera Juice 1X-CG⁶	Aloe Barbadensis Leaf Juice	2.00%	Active
	HYDRAFEEL 3 M²⁵	POLYGLYCERIN-3, PCA	0.20%	Moisturizer
A	Lavender Oil²⁰	Lavandula angustifolia oil	0.10%	Scent
B	Preservative	Preservative	Q.S	Preservative

Suppliers: 1. Dow Chemical; 2. DSM; 6. Concentrated Aloe Corporation(CAC); 13. Stepan; 14. ErcaWilmar; 20. S&S; 25.Sharon

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com





Reference Formula

Sample preparation date: 2023/04/19

PROCEDURE

1. Premix phase W1 well.
2. Add phase W2 to W1 and mix well.
3. Add phase W3, A, B separately to the main tank.

SPECIFICATION

APPEARANCE	: Clear to a little bit hazy liquid
PH VALUE	: Approx. 6.45 ± 0.5 (25°C)

The information given in this publication is based on our current knowledge and experience and maybe used at your discretion and risk. It does not relieve you from carrying out your own precautions and tests. We do not assume any liability in connection with your product or its use. You must comply with all applicable laws and regulations and observe all third party rights.

Recommendations contained, herein this Reference Formula, are advisory only.

4F-3, No. 100, Sec. 1, Jia Feng 11th Rd., Chupei, Hsin-Chu Hsien 30273, Taiwan, R. O. C.

TEL No. : 886-3-657-9279 FAX No. : 886-3-657-9278

Website : www.essence-plus.com E-MAIL : service@essence-plus.com

